



26227 Slimline 2" Sidebar with Step Ford F150 Crew Cab, 2009-

Included:

- Step bar driver side
- Step bar passenger side
- Hex nut x 12
- Flat washer x 12
- Lock washer x 12

Installation:

- 1) Review components and instructions. Set out the driver side and passenger side bars. Split hardware between the two sides. (Note the direction of the bar on the vehicle, see Fig 1.)
- 2) Have a helper hold the bar on one end. Place bar on side of cab and insert bolt studs through the pinch weld at pre-existing locations.
- 3) Use the included nuts and washers to fasten the bar to the vehicle.
- 4) Tighten all fasteners and then repeat procedure for other side.

